

solos™

CONNECTING YOUR ANT+ & BLE SENSORS - iOS

YOU NEED YOUR SOLOS HEADSET TO CONNECT TO ANT +

HOW TO CONNECT ANT+ AND BLE SENSORS

iOS

Step 1. Enable your iPhone's Bluetooth

Go to iPhone Settings > Bluetooth > Turn Bluetooth ON.

Step 2. Ensure that the ANT+ and Bluetooth sensors are awake. For example, for speed, cadence and power, pedal to wake the sensors and if you are using a heart rate monitor make sure you are wearing it.


If you are trying to connect an ANT+ sensor, you may have to hold the headset near the sensor.

***IMPORTANT:** Some cycling sensors can only be connected to one device at a time. Please ensure that your sensors are disconnected from other devices before searching for them using Solos.

Step 3. ANT+ and Bluetooth sensors should be listed on the connect to sensors screen.


*(You can scroll up and down to view more sensors.)

Step 4. If the sensor you want cannot be found, ensure that the sensors are awake and Search Again.




Step 5. Select the sensors that you wish to use.

When connecting to a sensor the icon in red will turn green when you have successfully connected and the “Auto Connect” option appears.



Step 6. Once connected, it is recommend that auto connect is selected. When using Solos in the future the auto connected sensors you selected will automatically connect.



Step 7. Press continue to move on to the final setup process.

*These same steps apply when connecting sensors from settings.

solos™

solos™

www.solos-wearables.com

© 2017 Solos Wearables™. All rights reserved.

Version: 1.43.0185. Rev.3.0